



Fig. 14: Welding in front apron

Area:

K — Spot weld or MIG (spot) with instrument panel in place. (working from passenger compartment side)

Finishing-off operations:

Grind all visible weld seams smooth.

Clean all weld seams with wire brush.

Prime all repaired areas. Apply standard seals.